






Jay R. Smith Mfg. Co.
Wholesaler's
Parts Order Number Guide

4020, 4021, 4023
4040, 4041, 4043
NEW STYLE

| PART | DESCRIPTION | ITEM NUMBER | |
|------|-------------|-------------|--|
|------|-------------|-------------|--|



**4020 to 4240 Parts
and Hardware**
NEW STYLE
Pg. 4-06-4-15

**Jay R. Smith Mfg. Co.
Wholesaler's
Parts Order Number Guide**



| PART | DESCRIPTION | ITEM NUMBER | |
|------|--|--------------|--|
| 1, 2 | NB Cover w/Screws, 2 thru 4" | 4020C04NB-NS | |
| 1, 2 | PB Cover w/Screws, 2 thru 4" | 4020C04PB-NS | |
| 3 | NB Rim f/4020 | 06178-70-1 | |
| 3 | PB Rim f/4020 | 06178-50-1 | |
| 1, 3 | NB Cover and Rim Only f/4" 4020 | 4020NBTOP-CA | |
| 1, 3 | PB Cover and Rim Only f/4" 4020 | 4020PBTOP-CA | |
| | | | |
| 1, 2 | NB Cover w/Screws, 2 thru 4" | 4040C04NB-NS | |
| 1, 2 | PB Cover w/Screws, 2 thru 4" | 4040C04PB-NS | |
| 3 | NB Rim f/4040 | 06159-70-1 | |
| 3 | PB Rim f/4040 | 06159-50-1 | |
| 1, 3 | NB Cover and Rim Only f/2-4" 4040 | 4040NBTOP-CA | |
| 1, 3 | PB Cover and Rim Only f/2-4" 4040 | 4040PBTOP-CA | |
| | | | |
| 2 | Screws f/NB Cvr, 4020-4240 ea (3 reqd) | 76053-80-6 | |
| 2 | Screws f/PB Cvr, 4020-4240 ea (3 reqd) | 76053-51-6 | |
| | | | |
| 1 | Cast Iron Cover Only, 2-4", 4220 | 06144-10-0 | |
| 3 | Heavy Duty Cast Iron Rim, 2-4", 4220 | 06189-10-0 | |
| | | | |
| | CI Tractor Cover f/2-4", 4240 | 05847-10-0 | |
| | DI Tractor Cover f/2-4", 4240 | 04888-20-0 | |
| | CI Rim and Frame Assembly, 4240 | 06197-10-4 | |
| | | | |
| 2 | Screws f/CI Cover 4220-4240, ea (3 reqd) | 76048-80-6 | |



**Jay R. Smith Mfg. Co.
Wholesaler's
Parts Order Number Guide**

**Misc Parts, 4020
to 4140 Top Assys
NEW STYLE
Cat Pg 4-06-4-10**

| PART | DESCRIPTION | ITEM NUMBER | |
|-------|-------------------------------|---------------|--|
| 4 | ABS Frame Assembly | 06161-42-4 | |
| 5 | Bronze CO Plug f/Gasket Seal | 06181-50-1 | |
| 5 | ABS CO Plug f/Gasket Seal | 06181-42-6 | |
| 6 | Gasket f/Gasket Seal Plug | 70094-94-6 | |
| 7 | Bronze CO Plug f/Taper Thread | 06963-50-1 | |
| 7 | ABS CO Plug f/Taper Thread | 06963-42-6 | |
| * | Thread Protector Cap | 76662-43-6 | |
| * | Thread Shield | 74425-43-6 | |
| 1,2,3 | NB Top Assembly f/2-5" | 4020NBTOP4-NS | |
| 1,2,3 | NB Top Assembly f/6" | 4020NBTOP6-NS | |
| 1,2,3 | PB Top Assembly f/2-5" | 4020PBTOP4-NS | |
| 1,2,3 | PB Top Assembly f/6" | 4020PBTOP6-NS | |
| 1,2,3 | NB Top Assembly f/2-5" | 4040NBTOP4-NS | |
| 1,2,3 | NB Top Assembly f/6" | 4040NBTOP6-NS | |
| 1,2,3 | PB Top Assembly f/2-5" | 4040PBTOP4-NS | |
| 1,2,3 | PB Top Assembly f/6" | 4040PBTOP6-NS | |
| 1,2,3 | NB Top Assembly f/2-5" | 4100NBTOP4-NS | |
| 1,2,3 | NB Top Assembly f/6" | 4100NBTOP6-NS | |
| 1,2,3 | PB Top Assembly f/2-5" | 4100PBTOP4-NS | |
| 1,2,3 | PB Top Assembly f/6" | 4100PBTOP6-NS | |
| 1,2,3 | NB Top Assembly f/2-5" | 4120NBTOP4-NS | |
| 1,2,3 | NB Top Assembly f/6" | 4120NBTOP6-NS | |
| 1,2,3 | PB Top Assembly f/2-5" | 4120PBTOP4-NS | |
| 1,2,3 | PB Top Assembly f/6" | 4120PBTOP6-NS | |
| 1,2,3 | NB Top Assembly f/2-5" | 4140NBTOP4-NS | |
| 1,2,3 | NB Top Assembly f/6" | 4140NBTOP6-NS | |